


Stepper Controller



Pinouts for ten pin connector:

PIN:	Function:
1	Ground
2	Ground
3	Step
4	Direction
5	Enable
6	Min
7	Max
8	Ground
9	Ground
10	Ground