



Pinouts for X, Y, & Z axis connectors:

| PIN: | Function: |
|------|-----------|
| 1    | Ground    |
| 2    | Ground    |
| 3    | Step      |
| 4    | Direction |
| 5    | Enable    |
| 6    | Min       |
| 7    | Max       |
| 8    | Ground    |
| 9    | Ground    |
| 10   | Ground    |